

ZGEMMA H11S

4K-UHD

Easy Setup Guide



More details please go to <http://www.zgemma.org>


Packaging Contents

Please check all package contents before using your product.


ZGEMMA H11S



User's Guide



HDMI Cable



AC Adapter



Remote Control

* The accessories may vary according to area.

Product Descriptions


Front Panel



1. “Air” logo LED

2. IR Receiver: Receive the IR signal from remote controller.

Rear Panel



1. DC Power Jack: Connect the provided AC/DC adapter (2A/12V)

2. Power Switch: Press to turn on/off the power

3. LNB IN

4. LOOP OUT: Connect to Satellite cable

5. Reset: USB update key

6. HDMI: Connect to TV using a HDMI cable for both audio and video signals

7. USB: USB2.0

8. ETHERNET: One Ethernet cable

9. TF Card slot

Remote Control

POWER
Press to turn the product on or standby

Numeric Keys
Press to enter a channel number or numbers according to the menu options

PREVIOUS
Press to go to Previous Page

BACK
Press to return to the previous service or Menu

Navigation Keys
Press to navigate up/down and left/right on the menu options. up/down keys are used to call up the channel list

EXIT
Press to exit the current menu option into the live mode, or switches one step back of the menu.

Volume +/-
Press to adjust the audio volume

TEXT
Press to display the teletext information of the current channel, if the channel provides teletext data.

TV
Press to display the TV channel list

Color Keys
RED, Green, Yellow & Blue Each key is assigned a specific function that may be different in each manu

Recording []
Press to start or stop recording media

STOP []
Press to stop playing media

Play/Pause []
Press to play the selected file(e.g. recording) at the normal speed or pause the live program or recording play

Previous Program []
Press to move to previous program

Next Program []
Press to move to Next program

TIMER
Press to view the Timer Schedule

Fast Rewind []
Faster rewind than the normal speed

Fast Forward []
Faster forward than the normal speed

SLEEP
Press to turn off the product sleep timer by user

MUTE
Press to mute the audio or un-mute

NEXT
Press to go to Next Page

INFO
Press to view the Program information

OK
Press to confirm the selected menu option

EPG
Press to display the EPG(Electronic Program Guide) information if the channel provide

Channel(Page) up/down
Press to navigate through the scanned channel list or move the channel/program list in pages

MENU
Press to main menu

FILE LIST
Press to display the list of recordings stored on the external HDD if any

AUDIO
Press to select available audio language and audio type

SUBTITLE
Press to display the subtitle of the current channel, if the channel provides subtitle data

PORTAL
Press to go to Portal menu

RADIO
Press to display the Radio channel


V.MODE
Press to change the display output ratio: Wide Zoom or Original

FAV
Show the Favorite Lists available

HELP
Press to display major important operation methods. This provides users with a quick guide of product


Connecting TV via HDMI cable

Connect your TV to ZGEMMA H11S using a HDMI cable as follows.



Power up

A power cord and an adapter are provided in the accessory box.



First Time Installation

Step 1. Video Input Selection

Video input selection

Please press OK if you can see this page on your TV or select a different input port.

The next input port will be automatically probed in 6 seconds.

English

HDMI



Step 2. Video Mode Selection

Video Mode Selection

English

720p

1080i


1080p

2160p

576p


480p


576i





Step 3. Language Selection

Please use the UP and DOWN keys to select your language.
Afterwards press the OK button.

 English

 German

 Catalan

 Croatian



Step 4. Conguring Satellite Connection

Welcome.

This start wizard will guide you through the basic setup of your STB.
Press the OK button on your remote control to move to the next step.

English

Use the up/down keys on your remote control to select an option. After that, press OK.

English

Use wizard to set up basic features

Exit wizard



Software update

- 1.Download new software file from <http://www.zgemma.org/downloads.html>
- 2.Copy the *_mmc.zip file to your usb stick
- 3.Insert the usb stick to your box then open your box
- 4.Press remote control menu key select standby>recovery>bootmenu>flash local image>transmemory>*_mmc.zip select boot1-4 press ok key
- 5.The flash will auto begin and go to end then you can select boot1-4 to start your box.