Format yoru usb with FAT32, do not with NTFS

Download openPLI from: https://openpli.org/download/zgemma/H17+combo/

Download the first one: openpli-develop-h17-20241021_usb.zip

Downloads for the Zgemma H17 combo	
Attention!	
Downloads labeled multiboot can not be flashed in the tradition multiboot slot of the receiver using the "Flash Image" menu op	
One Diffe Develop by Hel	
OpenPLi » Develop builds	
	2024/10/21 23:36 - 72.85ME
OpenPLI'> Develop builds openpli-develop-h17-20241021_usb.zip openpli-develop-h17-20241021_multiboot.zip	2024/10/21 23:36 - 72.85ME 2024/10/21 23:36 - 66.79ME
G→ openpli-develop-h17-20241021_usb.zip	

After download it, extract/unzip the zip file, copy all to the pendrive/usb stick

Put the usb stick into the box usb slot

Keep pressing the re-set key on rear panel, at the same time, use other hand to make box white button power on

The re set key show on:



After make power on, and keep pressing re set key for 2 to 3 seconds, and loose pressing, and the display will show "FLASH" word, and let it flash automatically, after flashing and the new image will re star